

## Questions about the T-Max Timer

**Parameter “.1”: Bed Address**

**Parameter “.3”: Delay Time**

**Parameter “.9”: Cleaning Dots**

### To Set Parameters:

1. Press and hold start/stop and up arrow at the same time. Wait until a “.1” appears.
2. Press the up or down arrow until you reach the parameter number you’d like to adjust.
3. Press the start/stop button to see what the current setting is for that parameter.
4. Press the up or down arrow to set the parameter to the new setting. (Note: If you want to clear the parameter, press the up and down arrows simultaneously until a “.0” is present.)
5. Once you have the desired parameter setting, press the start/stop button.

The display will show the parameter number you just changed, with a solid dot in front of it. You may now hit the up or down button to the next desired parameter you’d like to change. Once there, follow steps 3 through 5 once again.

6. To exit the parameter mode, hit the up and down buttons at the same time until the display shows a “0” with no dots.

### Starting a Session

1. Press the up or down arrow until you reach the desired time.
2. Press and release the start/stop button to start the session

\*The delay will appear with a flashing dot on the lower right corner. This is the delay time counting down. If the delay is set at zero, then the bed should just start. When the session starts the flashing dot will flash at once per second.

### Pausing a Session

1. To pause a session, press the start/stop button. The bed will shut down but the session time will continue to count down.
2. To restart, press the start/stop button. The bed will energize again and the display will start to flash once per second again.

### **Cancelling a Session**

1. Press the start/stop button.
2. Next press the up button.
3. The display will show either a “..”clean room display, or a “0”.

### **Setting the Bed Address**

1. Press the start/stop button and up button at the same time. Release the buttons once a “.1” is displayed.
2. Press and release the start/stop button. A dot/number will display with the number flashing. This is the current bed address.
3. Press the up or down arrow to change the bed address to the new number.
4. Press the start/stop button to enter the new bed address.
5. To exit: press and hold the up and down arrows until a “0” or “..” appears.

### **Setting the Delay Time**

1. Press the start/stop button and up button at the same time. Release the buttons once a “.1” is displayed.
2. Press the up button until a “.3” is displayed. This is parameter #3.
3. Press and release the start/stop button. A solid dot flashing number will appear. This is the current delay time.
4. Press up or down to the desired delay time.
5. Press the start/stop button until a solid “.3” is displayed.
6. To exit: press and hold the up and down arrows until a “0” or “..” appears.

### **Add/Remove the Clean Room Dots**

1. Press the start/stop button and up button at the same time. Release the buttons once a “.1” is displayed.
2. Press the up or down button until “.9” is displayed. This is parameter #9.
3. Press and release the start/stop button. A solid dot/flashing “1” or “0” will be displayed.
4. Press up or down. “1” means the cleaning dots are on. “0” means the cleaning dots are off.
5. Select “1” or “0” and press start/stop.
6. To exit: press and hold the up and down arrows until a “0” or “..” appears.